

This set is designed to fit the Big Planes Kit E-7 Wedgetail or P-8 Poseidon kit.
Important Note, if you are fitting the open bomb bay you will need to do some alterations to the plug.
Due to the limitations and flexibility of the moulds, some fuselage halves need adjusting. This is best done by soaking in boiling water for about 30 seconds and it can then be fitted inside the fuselage to get the correct fit,

