

AV-8B/Harrier GR.7 100% LERX

Parts list: LERX fairings (left and right)
 Firefighting access points (2)

1. Assemble kit wings and fuselage separately.
2. Remove moulded LERX, fit wing to fuselage, filling and filing to achieve smooth contours.
3. If holes appear because the kit moulding is not thick enough, *do not worry!* Reinforce from the inside with a piece of scrap plastic (pushed in through forward nozzle fairing) and fill with MILLIPUT or similar.
4. Check fit new LERX mouldings. As it has not been possible to mould the rear edges sufficiently thin, it will be necessary to recess the fuselage (about 0.3mm.) to accommodate them. Once superglued in place, the top surfaces can be smoothed in with filler and/or filed down.
5. When you are satisfied, glue the resin firefighting access points in place and complete the kit as normal.

