

Hamilton Hobbies - 1/48 RAAF UH-1H "Float" Conversion

This conversion is for experienced modellers only.



Main parts

- Floats x2
- Float pylon struts (metal) x2
- Rubber float shoes x2
- Boarding ladders x2
- Float Stabilisers x4

Construction

Step 1 – Take the front and rear float and glue them together. If you are con

Step 2 – Add the two foot runners to the underside of the float

Step 3 – glue the strut guides to each float, two for the front strut and two for the rear.

Step 4 – Glue the two aluminium struts to each flow. Please use the bottom of the Iroquois fuselage as a guide.

Step 5 – Once dry, glue the floats and struts to the Iroquois fuselage

Step 6 – Glue the access ladder to each of the floats



