



TIPS FOR WORKING WITH RESIN PARTS

NO MOLD RELEASES ARE USED - WASHING OF RESIN PARTS IS NOT NECESSARY. REMOVE MOLD BLOCKS FROM PARTS CAREFULLY WITH A HOBBY KNIFE OR SAW. WHEN REMOVING LARGE BLOCKS FROM PARTS SUCH AS SEATS, IT IS HELPFUL TO SUPERGLUE THE MOLD BLOCK TO A 1/2" WOODEN DOWEL TO USE AS A HANDLE DURING SAWING.

USE SUPERGLUE (CYANOACRYLATE) OR EPOXY TO ASSEMBLE RESIN PARTS. WHITE GLUE (PVA) CAN BE USED TO ATTACH SMALL PARTS, OR POSITION PARTS BEFORE FINAL GLUING.

CURED URETHANE RESIN PARTS ARE CHEMICALLY INERT. NUISANCE DUST IS CREATED DURING THE SANDING PROCESS, SO THE USE OF A DUST MASK IS RECOMMENDED.

KEEP AWAY FROM HEAT AND SUNLIGHT. WARPED PARTS CAN BE PLACED IN HOT WATER AND STRAIGHTENED, THEN INTO COLD WATER TO SET THE CORRECTION.

PHOTOETCHED PARTS CAN BE VERY SMALL AND SHARP. HANDLE WITH CARE. ASSEMBLE WITH SUPERGLUE, EPOXY OR WHITE GLUE (PVA).

**BARRACUDA STUDIOS
P.O. BOX 1013
FREMONT, CA 94538**

Made with Pride in the U.S.A.