

1/32 P-51D Mustang Canopy for the Revell kit

This is a replacement canopy set for the Revell kit cast in clear resin.

The flash on the part and casting blocks can be removed with a razor saw, sharp scalpel or a mini-tool. Once the main flash is removed a firm sanding board is best to smooth and trim back to the canopy frame line.

The canopy can be polished up using various model polishing compounds and or other polishing compounds, the Micro Mesh products work well, as do the various buffers supplied by many modelling supply shops as well as the buffers supplied by nail bars. DO NOT use a polishing tool, only polish by hand, extreme heat could distort or blemish the canopy.

The canopy can also be dipped in you favourite dipping, solutions such as FUTURE KLEAR or GAUZY products.

Super glues will not FOG or BLOOM the clear resin like it does with clear injected parts, however still use with care as it will be hard to remove and restore canopy if it is spilt on the clear sections.

I found that the canopy support in the kit is exceptionally weak, not aided that it is very thin and has many holes within, therefore I suggest backing it with a thin section of plastic card as shown, and once glue is cured trim and drill to suite. adjust the width ever so slightly if required to fit the canopy

