



Recomended kit: Airfix DC-9-30 Sheet 07

We wish to thank SCUTHERN AIRWAYS for their help and co-operation, Without which this decal would not

White

Small Fleet Number

Natural Metal

we recomend using the Micro-Scale decal system with our decals.

Use window punch supplied with kit to punch out windows. Fill windows with white glue or Kristal-Kleer. Be sure to clean out decal from window opennings before filling windows.

N89S was the first DC-9-30 acquired by Southern Airways.

Natural Metal

Apply the fuselege decals first, then add fin decals. Cockpit Framing: Natural Metal Inside of Wheel Wells: Very Lt. Gray Landing Gear Struts: Very Lt. Gray Natural Metal Oleo on Strut: Shiny Metal Wheels: Aluminum Tires: Very Dk. Gray Engine Pylons: White, top and Bottom Flap Hindges: Natural Metal White Flat Aluminum Flat Black Natural Metal Seal first window both sides Flat Black White Stained Darkened Metal

Note: Gray to meet wing root