

**Steel Beach  
1/48 F-18E/F Dropped Flaps  
For Revell kits**

This resin set allows you to drop the flaps on the Revell F-18E/F Super Hornet kits.

Included in this set are:

- A. Leading edge flaps
- B. Trailing edge flaps
- C. Cover plates
- D. Flap hinges

Instructions:

1. Cut out the leading and trailing edge flaps from the kit wings (both top and bottom). Refer to photos for where to make the cuts.
2. Fill the gaps in the wing root on the fuselage. Two part epoxy putty is recommended.
3. Glue the outer wings onto the inner wings
4. Glue the leading edge flaps in place. They glue directly to kit wings.
5. Glue the hinges in place. Refer to the kit instructions for placement. The hinges have a round piece at each hinge. This should face outward.
6. Glue the trailing edge flaps to the hinges. The trailing edge flaps should NOT touch the kit wings.
7. Glue on the cover plates to the back edge of the kit wings. The cover plates should hang down at an angle and cover the gap between the wing and the flaps.

