



USE A SAW TO REMOVE SUPPORTS  
FROM 3D PRINTED PARTS

**DETAILS AFTER REMOVAL  
FROM SUPPORTS**



PAINT INSTRUCTION

COLORS	GUNZE / AQUEOUS	GUNZE / MR.COLOR
KHAKI	H55	C55
CAMOUFLAGE		

COLORS	GUNZE / AQUEOUS	GUNZE / MR.COLOR
TAN	H44	C44
FLESH	H22	C22