

1. First, check all the links. Note: left and right side or additional links are treated separately.
2. Casts have to be trimmed from occurring barbes by a sharp craft knife. After that, you have to drill the bore in the link by a **0,5** mm drill. Note: you needn't drill the bore to its end open. Bore has to lead beyond the next connected link, but does not open on the other side of the link. That's the reason left and right side are separated.
3. Wash the casts slightly in warm water with a few detergent.
4. Cut pieces some mm longer than link bores from the attached wire, these will be the trackpin.
5. Push these into link bores connecting them together.
6. Drop a few cyanoacrilate adhesive into closed bore to fix end. When the adhesive fixed remove the excess part of pin.
7. Painting.