

FTC008

DOUGLAS AD-5W SKYRAIDER

CONTENTS

1 x Under fuselage radome.
1 x Rear canopy blank

PARENT KIT

REVELL/MONOGRAM AD-5 (A1-E)

CONSTRUCTION

All parts should be washed in warm, soapy water to remove any traces of mould release agent.

Referring to the accompanying drawing, the radome should be attached beneath the fuselage, faired in with filler and sanded to a smooth finish. The existing canopy, behind the pilot's section, should be replaced with the resin insert. We would suggest epoxy glue for this due to the danger of fogging the adjacent clear section if Super Glue is used. The rear of the insert is moulded slightly undersized to compensate for canopy cutting errors and may need to have a plasticard insert added.

