

BUCCANEER ACCESSORIES

- FTA001:- The new nose simply replaces that of the Airfix kit.
- FTA050:- The resin tailplanes and fin top fairing are accurately shaped and again merely replace those items in the Airfix kit, although in this case some cutting and filling will be required.
- FTA063:- Once removed from the carrier sprue and cleaning up the resultant surfaces, the RWR bullets are merely attached to the leading edges as shown.
- FTA070:- The two airbrakes are to be removed from the carrier sprue and the resultant edges cleaned up. The recesses are indented into the surfaces but can be drilled out deeper if required. The rear fuselage section replaces the Airfix section. You merely need to remove the corresponding section from the kit and replace it with the new item. The resin part is moulded on a plinth which should be gradually sanded away until a perfect fit is achieved. Filling may be required if you overdo it. The hinges can be made from plastic card. As differing lengths of hinge are visible according to the position of the airbrakes you should refer to photos of the particular aircraft you wish to model.
- FTA071:- These parts are merely cleaned up and attached to the model as shown.
- FTA067:- Once removed from the sprue and cleaned up the tanks are merely attached beneath the wings.

