

- 1) Paint model's upperside in FS 35630 overall and wait until the paint dries.
- 2) Place masks in the indicated places to cover zones that must remain painted in gray FS 35630. Continue painting the camouflage in the following order:
- -Darkest blue spots in FS 35180, an once dry, cover zones that must remain panted in FS 35630 & FS 35180.
- -Finish painting the uncover zones with medium blue FS 35250.