

FOKKER E.II / E.III



132512

WWW.HGWMODELS.CZ

Laser
ADVANCED TECHNOLOGIES

TEXTILE PART

PHOTOETCHED PART

1. Take the precut textile part out of the sheet.
2. Remove supporting paper.
3. Crumple the belt into a little ball and read it between the fingers.
4. Thread the belts through the buckles - use superglue.
5. Put the belts into the seat.
6. Spray by the glossy varnish.
7. Impregnate the belts with very diluted oil color (mix black and brown) - it will highlight the texture.
8. Spray by matt varnish.

After the varnish becomes dry it is possible to drybrush with light oil colour.

