


## Lockheed VR


## INSTRUCTION SHEET



T637 601

## IMPORTANT! READ THESE POINTS BEFORE YOU BEGIN

"TEST FIT" all parts before cementing. Trim excess plastic from parts before joining.



Use paint and cement made for styrene plastic only.

▶ Paint all sub-assemblies before attaching parts.

Scrape paint away from surfaces to be cemented together.

Follow all of the numbers on the instruction sheet beginning with number one.

TOOLS

IMPORTANT NOTE: Do not remove parts from runners until ready to use.







BRUSH OR PIN TO APPLY IT



CLOTHES PINS TO CLAMP AND HOLD PARTS UNTIL THEY ARE DRY.

## PAINTING YOUR MODEL

Use only paint made for styrene plastic models. You can create your own color scheme or follow the box cover illustration. For additional color detailing refer to instruction sheet. The following paints are suggested to duplicate cover illustration:

(A) - Fuselage, engine cowling: Pactra Candy Paga Gold over Insignia

Wing, vertical tail: Pactra Flesh.

Floats, struts: Pactra Flat Aluminum

Engine, cockpit: Pactra Flat Metallic Gray.

