




Grumman F4F-3 "Wildcat"(EARLY)

格鲁曼F4F-3"野猫"战斗机早期型

1:32 SCALE

READ BEFORE ASSEMBLY:

- This kit is not recommended for inexperienced modelers or for children under 14 years of age
- Study and understand these instructions thoroughly before beginning assembly
- When needed, remove photo-etch parts carefully using a modeling knife or photo etch sprue cutter, being careful not to damage or lose small parts.
- Take extra care in handling photo etch parts in order to avoid injury
- Apply instant cement sparingly to photo etch parts where instructed

- Tools recommended(not included in kit):Plastic and instant cements,sprue cutters,long nose pliers,,modeling knife, small files, tweezers, pin vise & scissors. Soft cloth and sandpaper will also assist in construction
- Glue and paint are not included in the kit. Use plastic cement and hobby paints only. Color guide for purchasing paint is included in the kit.
- Keep out of reach of small children. They must not be allowed to ingest small parts or handle plastic bags in any way.

装配之前仔细阅读

- 小心用模型锉刀锉平所有零件表面的注射浇口。
- 小心用刀片切下蚀刻片零件，不要遗失小零件。
- 用强力快干胶水粘合蚀刻片零件和金属轴。过量的快干胶水使用可能导致可动零件会粘住，小心涂胶。
- 取蚀刻片时应特别注意安全，防止利边划伤手指。
- 某些零件表面需贴水上贴纸，请选择在装配的同时进行。
- 推荐模型工具(自备)：胶水，水口剪刀，长咀钳，刀片，锉刀，镊子钳，钻，剪刀，瞬间快干胶。
- 软布同砂纸同时也应该是必备工具。
- 请使用塑料胶水和油漆，模型内不含。
- 谨防小孩吸吮塑料零件，或者将塑料袋套在头上，制作时应将套材远离小孩接触。
- 本产品不适合14岁以下没有经验的模型爱好者。

水贴纸的使用:

1. 从水贴上剪下印花;
2. 将印花放入温水中浸10秒, 然后放在干净布上.
3. 拿着印花纸将印花移到模型上;
4. 手指蘸水将印花移到适当的位置;
5. 用软布轻压印花直至水干, 气泡消失.

DECAL APPLICATION:


- 1.Cut decals from sheet as needed
2. Dip the decal in warm water for about 10 seconds and then place on soft clean cloth.
3. Hold the decal backing sheet edge and gently slide the decal onto the model in its proper position.

4. While still wet,decal can be adjusted for better fit on model by dampening it gently with your finger.
5. When placed in the proper position,gently press decal down with a soft cloth until excess water and air bubbles are gone.
6. Allow decal to dry completely before handling model




部品图 Parts


A




E



C




D




部品图 Parts

H




G



不用的部件: A10,C1,C2,C3,C4,C5,C14,C15,C19,C20,C21,C22,C23,C26,C27,K4

Unused parts:

K



引擎罩
Cowling




小轮胎
Small tire



大轮胎
Large tire


蚀刻片

Photo Etched parts(PE)



水贴

Decal



菲林

Film



轴


Shaft

φ1.0×50.0 2PCS


φ1.0×44.0 6PCS

φ1.0×26.0 1PCS


1 座舱的组装 Cockpit assembly




2 座舱的组装 Cockpit assembly




3 发动机的组装 Engine assembly




4 发动机的组装 Engine assembly





5 发动机的组装 Engine assembly




6 主轮舱的组装 Main gear cabin assembly




7 右机身的组装 Right fuselage assembly




8 左机身的组装 Left fuselage assembly




9 方向舵的组装 Rudder assembly







11 右侧水平尾翼的组装 Starboard horizontal stabilizer assembly








12 左侧水平尾翼的组装 Port horizontal stabilizer assembly




13 主起落架的组装 Main undercarriage assembly





14 左侧机翼组装 Left wing assembly



15 左侧机翼组装
Left wing assembly






16 右侧机翼组装
Right wing assembly




17 右侧机翼组装
Right wing assembly

H 340 340
原野绿
Field Green


H2



H9







18 机翼的安装
Wings installation




19


主起落架的安装

Main undercarriage installation





21 座舱罩的安装
Canopy installation



A

VF-41 USS RANGER (CV-4), 1941

Gunze		H 8 8	银色 Silver	H 90 47	透明红 Clear Red	H 135	苏联绿 Russian Green(1)
H 94	透明绿 Clear Green	H 18 28	黑铁色 Metal Black	H 76 61	烧铁色 Burnt Iron	H 77 137	胎黑色 Tire Black
H 2 2	黑色 Black	H 12 33	亚光黑 Flat black	H 311 311	灰色 Grey	H 329 329	黄色 Orange Yellow

