



48069



F-86D SABRE DOGS

PART II



SUGGESTED KIT: REVELL GERMANY F-86D SABRE DOG

F-86D SABRE DOG

F-86D SABRE DOGS


48069

PART II

These particular A/C are a later D model, and have a parachute housing on the tail. You must use the Revell Germany kit or make your own alterations.

1


F-86D, 53-1001 "TEXAS TERROR". Flown by Col. Grover Wilcox, Air Division Commander, Geiger Tigers, 498 FIS, Yuma 1956. Overall aluminum with Green 42 anti-glare panel and Black radome. Blue trim on the fin, canopy, drop tanks and nose gear door must be painted by modeller.



Use stencils and wing walk decals from kit.

2


F-86D, 52-4020. Flown by the 51st FIW Commander, Formosa 1955. Overall aluminum with Green 42 anti-glare panel and Black radome.



After all painting is done, place the airbrakes over its fuselage position. Place decal 14 (US insignia and bars) on its position. When dry and with a brand new #11 knife, cut along the panel line. When it become separated, apply some solvent solution (Micro, Aero or Super.)



NOTE: Edge with 4 black squares points FORWARD.



COLOR SCHEMES




ALUMINUM



F.S. 34092



MED. BLUE
APROX. F.S. 15052



EAGLE STRIKE
Productions
EAGLE STRIKE
2025 S.W. 22 Terrace
Miami, FL 33145 U.S.A
fax (305) 285-7219

48069

Recommended Kits:

- Revell Germany F-86D Sabre Dog.

References:

- Photos received from Larry Davis
- S/S F-86 in Action.

THANKS LARRY!!

Decaling: Apply decals only to a glossy surface.

1. With a sharp scissors or knife, carefully cut item to be used, being careful of not cutting off the clear film around it or that belonging to an adjacent item.
2. Submerge in clean tap water for over 10 seconds and lay over an absorbent paper towel. Decal will slide freely in about 20 seconds. Do not leave decal on water bowl over ten seconds, or adhesive quality will suffer.
3. With a clean brush, apply a setting solution to the area where the decal will finally lay. (Micro, Super or Aero Set will do). With a clean pointed brush slide the decal on to the final area. Allow the setting solution to dry for about 3-5 minutes.
4. With another clean brush, apply a solvent solution over the decal (Micro, Super or Aero Sol will do). Do this if possible in one stroke since your decal will soften up and wrinkle immediately. This is an important step in the process, whatever you do **DO NOT TOUCH THE DECAL**, after this process until it is totally dry, preferably overnight.
5. When thoroughly dry, rinse your model with tap water and mild soap to wash of excess glue.
6. Finish your model with the desired final coat (gloss, flat, or semi-gloss).