
yal Model by Reale R

MLRS Multiple launch roket system

No. 023



The parts included in this kit are to be assembled in conjunction with the Dragon kit. For best results in the assembling of photo-etched and resin parts use cyanoacrylate glue. Always remember to use cyanoacrylate glue in a well ventilated area. Before assembly be sure to remove all parts to be substituted with photo-etched and resin parts. It is advised before assembly to study well the instructions which accompany this MICRODETAILS SET plus any other sufficient documentation. Note that some particulars illustrated in the instructions have been enlarged for easy identification. If distorsion occurs in some resin parts due to humidity immerge in hot water and reform.

O Substitute the plastic part with the photo-etched part

Repeat same operation for the other side.

