

# Phantom Phamily

McDonnell Douglas F-4B/J/N/S Phantom II






**CAM DECALS** are high quality thin film decals that enable you to produce museum quality aircraft models. For a realistic "painted-on" look, we recommend applying **CAM DECALS** utilizing **MICROSCALE'S MODEL FINISHING PRODUCTS**, which are formulated to work perfectly with these **CAM DECALS**. Microscale Model Finishing Products are available from your favorite hobby retailer. Follow these easy application steps to achieve perfect results every time:

- 1 - The ideal surface on which to apply decals is a glossy, painted finish. Unpainted surfaces do not allow decals to adhere properly. If flat paint has been used on the model, overcoat the model with a clear gloss before applying decals.
  - 2 - Cut each decal from the sheet as you need them. It is *not* necessary to trim the film that surrounds the image, as the clear film on **CAM DECALS** is designed with a taper at the edges in order to make hiding this film easy.
  - 3 - Submerge the cut decal piece in clean, room temperature water for approximately 10 to 15 seconds, then remove the decal from the water. After one or two minutes (depending on the size of the decal) the decal should slide freely on the paper backing.
  - 4 - While waiting for the decal to release from the paper backing, apply **MICROSCALE'S MICRO SET** to the area of the model where the decal is to be applied. This will help eliminate unsightly air bubbles from getting trapped under the decal, and will begin the process of softening the decal in order for it to conform to the model's surface irregularities.
  - 5 - Using a pair of tweezers, hold the backing paper of the wet decal and slide the decal itself onto the "puddle" of **MICRO SET** on the surface of the model using a small artist's brush.
  - 6 - Carefully position the decal using the tip of the artist's brush. Do not use your fingers! When the final position has been achieved, carefully remove any excess water and **Micro Set** with a tissue.
  - 7 - Allow the decal to settle for five to ten minutes, then re-wet the decal using **MICROSCALE MICRO SOL**. This will further soften the decal to make it conform perfectly to irregularities on the model's surface.
  - 8 - You may notice some wrinkling of the decal after the application of **MICRO SOL**. This is normal. *Do not touch the decal until it is dry.* Allow the decal to dry for several hours.
  - 9 - After the decal has dried, check for air bubbles that may have become trapped under the decal's surface. If any are found, prick them with a needle or hobby knife tip and apply a second application of **MICRO SOL**. Allow the decal to dry. Repeat if necessary.
  - 10 - After all air bubbles have been eliminated and the decals are completely dry, wash the model with water to remove any residue from the decal adhesive.
  - 11 - When the entire model is free of all excess decal adhesive and completely dry, overcoat the model with your choice of clear finishes (gloss, flat or satin, depending on your preference).
- Store unused **CAM DECALS** in a cool, dry place. Avoid prolonged exposure to sunlight, fluorescent light, dampness and extremes of temperature and humidity. Proper storage should give your **CAM DECALS** many years of storage life. If, however, you suspect that a decal may have developed cracks in its film over time, apply **MICROSCALE LIQUID DECAL FILM** in order to rejuvenate the decal film.

**CAM DECALS**  
10 Potomac  
Irvine, CA 92620-3254  
(949) 786-1488

48-081

**CAM** 2000  
CUSTOM AERONAUTICAL MINIATURES



486  
Place on front nose  
wheel door

Place on rear nose  
wheel door

McDonnell Douglas FGR.2 Phantom II  
No. 56 Squadron Royal Air Force  
60th Anniversary Alcock and Brown Markings  
1979

Position of numbers on bottom of wing  
shown with dashed lines

Recommended kit:  
Tamiya 1/32 scale F-4J and  
Custom Aeronautical Miniatures  
F-4M Conversion kit

Custom Aeronautical Miniatures  
10 Potomac  
Irvine CA 92620  
www.camdecals.com



XV424



486

ROYAL AIR FORCE



48-081A

Art by  
MODEL  
GRAPHICS

FLT LT WN  
BROWNE  
FLT LT WN  
BROWNE



NATO THIRTIETH ANNIVERSARY

NATO THIRTIETH ANNIVERSARY



SON LDR A J H  
ALCOCK  
MBE  
SON LDR A J H  
ALCOCK  
MBE



ROYAL AIR FORCE

XV424



CAM  
CUSTOM AERONAUTICAL MINIATURES

ROLLS ROYCE  
**1919-FIRST NON-STOP TRANSATLANTIC FLIGHT**

**1919-FIRST NON-STOP TRANSATLANTIC FLIGHT**



**1919 ROLLS-ROYCE EAGLE**  
**1979 ROLLS-ROYCE SPEY**



**1919 ROLLS-ROYCE EAGLE**  
**1979 ROLLS-ROYCE SPEY**

**ALCOCK AND BROWN**

SHIPPA  
3000  
As An

**ALCOCK AND BROWN**

**CAM**  
CUSTOM AERONAUTICAL MINIATURES

48-081B

