


**DRAW
Decal**

Set 20s-767-55A Qantas Freight 767-381F

"Civil Decals for the Civilized"

In February 2011, Qantas Freight (a subsidiary of Qantas Airways) took delivery of a Boeing 767-381 Freighter. Previously operated by All Nippon Airways (ANA), the aircraft was delivered in full Qantas colors, minus the world-famous kangaroo on the tail, and later operated with updated titles and the "roo" added to the tail. Operated by Express Freighters Australia, VH-EFR operates the "Tasman" route to New Zealand in this updated livery.



200 SCALE


COPYRIGHT © 2023 DRAWDecal.com

Greg Drawbaugh
DRAWDecal.com

DIGITAL
Silk
Next Generation

DRAW Set 20s-767-55A
Decal qantas Freight 767-381F

Operated By
EXPRESS FREIGHTERS
Australia



Nose Gear Door Detail




The fuselage and engine nacelles are gloss white. Vertical stabilizer and rear fuselage are gloss red. The demarcation lines of the red on the fuselage are aligned with the forward and trailing edges of the vertical stabilizer. Wings and horizontal stabilizers are Boeing Gray with corogard center sections. As a factory-built freighter, the forward entry door is the only cabin exit installed. Express Freighters Australia titles are applied just aft of the cockpit, even with it. BOEING 767-300F titles are located mid fuselage even with the bottom edge of the cockpit, even with it. Registration are applied to the rear fuselage. Large registration is placed on the underside of the Qantas titles. Australian flag and letter ship ID is applied to the top of the rudder. Black two-letter ship ID is located on the nose gear doors with the red towbar limit stripe. As always, check photo references when building your model.

BOEING 767-300F

BOEING 767-300F

Operated By
EXPRESS FREIGHTERS
Australia



We strongly urge you to fill in the kit's open windows prior to painting. Wings and horizontal stabs have standard bare metal leading edges, always consult prototype photos.

DRAW Set 20s-767-55A
Decal Qantas Freight 767-381F

200 SCALE



Recommended Kit:
 1:144 Hasegawa 767-300 w/ GE Engines

Please note that filling in the kit's windows and door scribing will work best to allow the decal to fit properly.

PLEASE NOTE: ALL decals need to be applied to a smooth and glossy surface!

PLEASE READ THESE INSTRUCTIONS, as these decals may apply a bit differently than you may be used to using.

Next Generation DIGITAL Silk decals are extremely durable and do not easily scratch, and are printed on a continuous, clear film. Each design will need to be cut out individually. **Next Generation** DIGITAL Silk decals do not generally need to be clear coated prior to use. Use care when applying as the decal film is **exceptionally** thin. **Next Generation** DIGITAL Silk decals are tough, durable and exceptionally *flexible*. **DO NOT** float the decal off of the backing paper, as it will curl up and likely become unusable. Rather, soak the decal in warm water for about 5 seconds then remove it and allow it to sit for 30 seconds before trying to slide it off of the backing paper. "Normal" decal setting solutions can be used with these decals but will have little effect. For most applications, NO decal solvent will be needed. If you feel the need, we recommend using Microscale's Micro Set (a wetting agent) and Micro Sol (a SOLvent), but note the decal solvents only effect the clear film and have **LITTLE** effect on the inks. Brush the Micro Set directly on your model before sliding the decal into position. Only slide a small portion of the decal off of the backing paper, place the decal into position then pull out the backing paper allowing the decal to land in place. After you adjust the decal into position and soak up the excess liquid, apply a thin coat of Micro Sol (the **solvent**) to soften the clear carrier. It is important to get the Micro Sol **under** the decal, as the solvent has little effect on the ink, but it will dissolve the clear carrier which allows the decal to dig into the paint. After this coat dries and you are certain the decal is in its final position, apply a second heavier coat of Micro Sol. Note repeated applications of decal solvent will only wash away the glue. After the decals are **completely** dry, clear coating your model after applying these (or any) decals is a **must!** I repeat this is a **must**. The clear coat will seal your decal and prevent it from becoming damaged. Airbrush lacquers only in very light, misting coats. Another method to clear coat the decal is to use Future acrylic floor polish. Good luck and thank you for using **Next Generation** DIGITAL Silk decals!

QANTAS FREIGHT

1:200 Scale

Static Ports

L Pitots R Pitots

FR FR

Relief Valves

AFT

VH-EFR VH-EFR VH-EFR

QANTAS FREIGHT

DRAWDecal.com

DIGITAL Silk DRAW Decal Set 20s-767-55A Qantas Freight 767-381F