


# DRAW Decal Set 72s-P51-15

"Slender, Tender And Tall" P-51D

1/72 Scale



## Recommended Kits:


- 1:72 Airfix P-51D
- 1:72 Tamiya P-51D

**PLEASE READ THESE INSTRUCTIONS**, as these decals may apply a bit differently than you may be used to using. **Next Generation** DIGITAL Silk decals are extremely durable and do not easily scratch, and are printed on a continuous, clear film. Each design will need to be cut out individually. **Next Generation** DIGITAL Silk decals do not generally need to be clear coated prior to use. Use care when applying as the decal film is **extremely** thin. **Next Generation** DIGITAL Silk decals are tough, durable and now exceptionally *flexible*. **DO NOT** float the decal off of the backing paper, as it will soak off the glue and become unusable. Rather, soak the decal in warm water for about 20 seconds then remove it and allow it to sit for 30 seconds before trying to slide it off of the backing paper. "Normal" decal setting solutions can be used with these decals but will have little effect. For most applications, NO decal solvent will be needed. If you feel the need, we recommend using Microscale's Micro Set (a wetting agent) and Micro Sol (a SOLvent), but note the decal solvents only effect the clear film and have **LITTLE** effect on the inks. Brush the Micro Set directly on your model before sliding the decal into position. After you slide the decal into position and soak up the excess liquid, apply a thin coat of Micro Sol (the **solvent**) to soften the clear carrier. It is important to get the Micro Sol **under** the decal, as the solvent has little effect on the ink, but it will dissolve the clear carrier which allows the decal to dig into the paint. After this coat dries and you are certain the decal is in its final position, apply a second heavier coat of Micro Sol. Another method to try is to use a cloth soaked in **HOT** water to press the decal into place over rivets, panels lines and other contours. **Just a reminder, HEAT** is the best final option to make the ink bend and **conform**; repeated applications of decal solvent will only wash away the glue. After the decals are **completely** dry, clear coating your model after applying these (or any) decals is a **must!** I repeat this is a **must**. The clear coat will seal your decal and prevent it from becoming damaged. Airbrush lacquers only in very light, misting coats. Another method to clear coat the decal is to use Future acrylic floor polish. Good luck and thank you for using **Next Generation** DIGITAL Silk decals!

# DRAW Decal Set 72s-P51-15

"Slender, Tender And Tall" P-51D

"Civil Decals for the Civilized"



*Slender, Tender & TALL*

"Slender, Tender And Tall" is marked for the aircraft of Lt. Col. William T Halton of the 352nd Fighter Group.



Artwork by  
Tony Andrews

Gathering Of Mustangs And Legends  
Columbus Ohio 2007


DIGITAL  
*Silk*  
Next Generation

COPYRIGHT © 2017 DRAWDecal.com

MILITARY 72

# DRAW Decal Set 72s-P51-15

## "Slender, Tender And Tall" P-51D




"Slender, Tender And Tall", N51DT, owned by Tom Blair is finished with a polished bare metal fuselage and painted silvery-grey wings along with the blue nose and tail of the 352nd Fighter Group and black recognition bands round the tailplanes.

Propellor: Hamilton Standard paddleblade.

Antennae: standard aerial post on the spine, forward-facing VOR antennae at the top of the fin, comms aerial and transponder behind each wheel well.

Vents in the panels behind the wings are represented as decals



Artwork by  
Tony Andrews

[47], [48] but would better be fabricated from e.g. 1/4 round rod.