


SHIPPING TICKET
500 LB
M521982
0171054
00 06 71942
5.5 CU FT
52
54
53
LOT 667
EXPLOSIVE
BOMB
10 20 1943
FROM PICATINNY ARSENAL
500 lb. Bomb (Plan view)

SHIPPING TICKET
1000 LB
M444
04 22 1942
10.5 CU FT
55
57
56
LOT 883
EXPLOSIVE
BOMB
11 01 1943
FROM PICATINNY ARSENAL
1000 lb Bomb (plan view)





The preparation of the surface prior to the application of the **HGW Wet Transfer**:









- The HGW Wet Transfer technology has been tested on Gunze brand paints and preparations.
- Carry out the test (not on the model), if you are applying to paint made by a different manufacturer.
- We recommend to spray the surface with a glossy varnish in order to achieve a perfect result.
- No matter whether you are applying the transfer onto paint or varnish, it is advisable to go over the surface using sandpaper of a grade from 6 000 to 8 000.
- Naturally, it is also essential to ensure that the base is clean, grease-free and clear of dust.

You will need:

- a scalpel,
- sharp tweezers,
- the Mr. Mark Softer / Setter product by Gunze,
- a cotton bud and a clean cloth.

WWW.HGWMODELS.CZ

WET TRANSFER

<p>1 Cut out the required design using a sharp scalpel.</p> 	<p>2 Soak the base paper in warm water (approx. 20 sec).</p> 	<p>3 Remove the transfer from the base paper.</p> 
<p>4 Apply a layer of Mr. Mark Softer or Mr. Mark Setter on the surface where you intend to apply the transfer.</p> <p>Mr. Mark Softer / Mr. Mark Setter</p> 	<p>5 Place the transfer in the required position on the layer of Mr. Mark Softer or Mr. Mark Setter.</p> <p>Mr. Mark Softer / Mr. Mark Setter</p> 	<p>6 Carefully press out any excess liquid and bubbles. (Use the cloth and the cotton bud.)</p> 
<p>7 Ideally, leave it to dry for 6-8 hours.</p> <p>6-8 hours</p> 	<p>8 Carefully remove the transparent transfer film.</p> 	<p>9 Clean off any traces of transfer glue with a wet cloth.</p> 