


F-104A Super Detailed Cockpit Set



with Lockheed C-1 Ejection Seat for Hasegawa

CEC48253


















General Notes:

- Your **Cutting Edge Modelworks** super detailed cockpit fits the Hasegawa F-104C kit with some work. These instructions are for the Hasegawa kit; you're on your own to fit it into the Monogram kit.
- This set contains an "A" model cockpit only. You are on your own for any other airframe modifications to make a F-104A. Note that while the F-104A was originally built with the Lockheed C-1 downward ejection seat (included with this set), most were retrofitted with the Lockheed C-2 Upward Ejection Set, available from Cutting Edge in set CEC48254 (with belts) and CEC48255 (without belts).
- BE CAREFUL if you're using the Hasegawa kit; their styrene is extremely brittle and easily cracks when it's being cut or sliced.
- CERTAIN PARTS ARE DELICATE! Please be careful with the slender parts.
- Dry fit all parts first. Measure twice and cut once!
- Use super glue (cyanoacrylate).



Construction Notes:

- Remove all molded in mounting lugs and cockpit sidewall details from the front fuselage halves. Remove the entire casting plug from the front of the cockpit tub.
- Remove the rear bulkhead from the casting sprue. Be sure to remove the crosshatched areas on the sides of the bulkhead so it looks like Figure 1 in side view.
- Glue rear bulkhead in place as shown in Figure 2. It will fit properly only if you've removed the crosshatched areas on the sides of the bulkhead.
- Fit—BUT DO NOT GLUE—the cockpit tub in place on the right fuselage half. Draw a line along the top of side console to show the position for the upper side wall. Repeat for the left fuselage side. See Figures 3 & 4.
- Glue the upper sidewalls in place per Figure 6. We recommend using Testors Liquid Cement (or other slow set liquid cement) to tack the parts in place, then checking their positions with the cockpit tub. When properly positioned, use a small amount of superglue around the edges to permanently affix the parts.
- Attach the rudder pedals per Figure 7 and stick, Hasegawa kit throttle, and resin lower instrument panel per Figure 8. The proper angles for these parts are shown in Figure 9. Figure 10 shows the cockpit tub complete except for seat related parts. You have a choice of painting the instrument panel dials or sanding off the thin backing plate and attaching the acetate instrument.
- Attach the "D" ring to the center of the ejection seat per Figures 11 & 12.
- Attach the ejection seat rails per Figures 13 & 14. The seat will slide down between the two rails when they are properly attached.
- The seat can be inserted now or when your model is finished (see Figures 15 & 16).
- Attach the upper instrument panel to the bottom of the cockpit coaming per Figures 17 & 18.
- Glue the front fuselage halves together, then insert the completed cockpit tub from the bottom. Don't glue the Hasegawa lower fuselage (kit part L1) in place until the cockpit is in place. Glue the coaming/upper instrument panel assembly in place. See Figures 19 & 20.



... proudly presented by:



P.O. Box 3956
Merrifield, VA 22116 USA
703/971-0500
FAX: 703/971-8111

www.meteorprod.com

© 2000 Cutting Edge Modelworks

Write for our 125+ page catalog!